
Configuring DHCP server on a Router

1. Build the network topology:



2. On the router, configure *interface* fa0/0 to act as the default gateway for our LAN.

Router>enable
Router#config terminal
Router(config)#int fa0/0
Router(config-if)#ip add 192.168.1.1 255.255.255.0
Router(config-if)#no shutdown
Router(config-if)#exit

3. Configure DHCP server on the Router. In the server we will define a **DHCP pool** of IP addresses to be assigned to hosts, a **Default gateway** for the LAN and a **DNS Server**.

Router(config)#
Router(config)#ip dhcp pool MY_LAN
Router(dhcp-config)#network 192.168.1.0 255.255.255.0
Router(dhcp-config)#default-router 192.168.1.1
Router(dhcp-config)#dns-server 192.168.1.10

We can add ip dhcp excluded-address command to our configuration so as to configure the router to exclude addresses 192.168.1.1 through 192.168.1.10 when assigning addresses to clients. The **ip dhcp excluded-address** command may be used to reserve addresses that are statically assigned to key hosts.


So add the above command under the **global configuration mode**.

Router(config)#ip dhcp excluded-address 192.168.1.1 192.168.1.10

4. Now go to every PC and on their **IP configuration** tabs, enable **DHCP**. Every PC should be able to obtain an IP address, default gateway and DNS server, as defined in step 2.

For example, to enable DHCP on PC1:

Click PC1->Desktop->IP configuration. Then enable DHCP:



Do this for the other PCs.

You can test the configuration by pinging PC2 from PC1. Ping should succeed.

It's that simple!